

INSTRUCTIONS AND PARTS MANUAL

CW-5 CIRCLE WELDER

Please record your equipment identification information below for future reference. This information can be found on your machine nameplate.

Model Number _____

Serial Number _____

Date of Purchase _____

Whenever you request replacement parts or information on this equipment, always supply the information you have recorded above.



CYPRESS WELDING EQUIPMENT INC.

CE

A DIVISION OF WELD TOOLING CORPORATION

3001 West Carson Street • Pittsburgh, PA USA 15204-1899

Telephone: 1-412-331-1776 • 1-800-245-3186 • Fax: 1-412-331-0383

<http://www.cypressweld.com>


SAFETY

PROTECT YOURSELF AND OTHERS FROM SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



ELECTRIC SHOCK can kill.

- 1) The equipment is not waterproof. Using the unit in a wet environment may result in serious injury. Do not touch equipment when wet or standing in a wet location.
- 2) The unused connectors have power on them. Always keep the unused connectors covered with the supplied protective panels. Operation of the machine without the protective panels may result in injury.
- 3) Never open the equipment without first unplugging the power cord or serious injury may result.
- 4) Verify the customer-supplied power connections are made in accordance with all applicable local and national electrical safety codes. If none exist, use International Electric Code (IEC) 950.
- 5) Never remove or bypass the equipment power cord ground. Verify the equipment is grounded in accordance with all applicable local and national electrical safety codes. If none exist, use International Electric Code (IEC) 950.



READ INSTRUCTIONS.

Read the instruction manual before installing and using the equipment.



EQUIPMENT DAMAGE POSSIBLE.

- 1) Do not plug in the power cord without first verifying the equipment is OFF and the cord input voltage is the same as required by the machine or serious damage may result.
- 2) Always verify both the pinion and wheels are fully engaged before applying power or equipment damage may occur.
- 3) Do not leave the equipment unattended.
- 4) Remove from the worksite and store in a safe location when not in use.



FALLING EQUIPMENT can cause serious personal injury and equipment damage.

Faulty or careless user installation is possible. As a result, never stand or walk underneath equipment.



MOVING PARTS can cause serious injury.

- 1) Never try to stop the pinion from moving except by removing power or by using the STOP control.
- 2) Do not remove any protective panels, covers or guards and operate equipment.

HIGH FREQUENCY WARNINGS

SPECIAL PRECAUTIONS ARE REQUIRED WHEN USING PLASMA, TIG OR ANY WELDING PROCESS THAT USES HIGH FREQUENCY TO STRIKE AN ARC.



WARNING: HIGH FREQUENCY CAN EFFECT MACHINE OPERATION AND THEREFORE, WELD QUALITY.

Read the precautions below before installing and using the equipment.

PRECAUTIONS:

- 1) Some plasma or welding cables are strong sources of high frequency interference. NEVER lay a plasma or welding cable across the controls of the machine.
- 2) Always physically separate the plasma or welding cable leads from the machine cables. For example, the plasma or welding cable leads should NEVER be bundled with a pendant cable or the machine power cord. Maximize the separation between any machine cables and the plasma or welding cables.
- 3) Strictly follow the grounding procedures specified for the plasma or welding unit. NOTE: Some plasma and welding units produce exceptionally large amounts of high frequency noise. They may require a grounding rod be driven into the earth within six feet (2 meters) of the plasma or welding unit to become compatible with an automatic cutting or welding process.
- 4) If the high frequency is produced using a spark gap, adjust the points so the gap is as small as possible. The larger the gap, the higher the voltage and the higher the interference.
- 5) Some plasma or welding units will inject high frequency interference into the AC power line. Use separate power line branches whenever possible to power the plasma or welding source and the machine. Do not plug them into the same outlet box.
- 6) High frequency noise may enter the machine through the plasma or welding supply remote contactor leads. Some plasma and welding sources can produce noise spikes of up to several thousand volts. These sources are not compatible with automated cutting and welding equipment. It is recommended that the remote contactor leads on these plasma or welding sources not be connected to the machine. An alternate solution is to purchase a separate remote contactor isolation box.

CW-5 CIRCLE WELDER

INSTRUCTIONS AND PARTS MANUAL

TABLE OF CONTENTS

PAGE

5	Introduction / Features / Set-Up and Operation
7	CWO-3332 Wire Feeder Controls
8	CWO-6110 Rotation Controls
9	Technical Data / Dimensions
10	CW-5 Circle Welder / Parts List
11	CW-5 Circle Welder / Exploded View
12	CW-5 Circle Welder / Wiring Diagram / Component Chart
13	CWO-1670 CW-5 Racking System / Exploded View / Parts List
	CWO-1685 Horizontal Racker / Exploded View / Parts List
14	CWO-3001 Shaft Assembly / Exploded View / Parts List
	CWO-3004 Cam Shaft and Spacer Assembly / Exploded View / Parts List
15	CWO-3005 5" Cam Assembly / Exploded View / Parts List
	CWO-3008 Wire Reel Mount Assembly / Exploded View / Parts List
16	CWO-3059 Large Brush Holder and Support / Exploded View / Parts List
	CWO-3384 P.M. Motor Assembly #146 / Exploded View / Parts List
17	CWO-3332 GMA Wire Feeder Control / Exploded View / Parts List
18	CWO-3332 GMA Wire Feeder Control / Wiring Diagram / Component Chart
19	CWO-3418 Transmission 3.5:1 Assembly / Exploded View / Parts List
	CWO-3462 Small Brush Holder Assembly / Exploded View / Parts List
	CWO-3461 Small Retainer Block Assembly / Detail View
20	CWO-6110 Rotation Control / Exploded View / Parts List
21	CWO-6110 Rotation Control / Wiring Diagram / Component Chart
22	CW-5 Gun Assemblies
23	#4 Gun and Cable Assembly / Exploded View / Parts List
24	CW-5 Drive Roll Kits
25,26	.	Accessories
27	Carriages
28,29	.	Set-up Instructions For CW-5 / CB-1P Used In Sprinkler Fabrication
30	Set-up Diagram For CW-5 / CB-1P Used In Sprinkler Fabrication
31	Preventive Maintenance / CW-5 Circle Welder

Patents Pending

LIT-CW-5-IPM-0704

INTRODUCTION

The CW-5 Circle Welder is designed for circular single or multi-pass welding of couplings on sprinkler pipe utilizing MIG or FLUX CORED process, with gas shielding. For one to twelve inch diameter welds.

Features:

- Amperage & wire speed control.
- Wire feeder with one set of drive rolls.
- 1/12 HP P.M. motor and rotational speed control.
- 300 AMP Gun & cable assembly.
- Gas shielding kit with 120 VAC solenoid valve.
- 5/8" (16 mm) gas cup.
- Burn back control.
- 50 ft. (15 m) power cable.
- 50 ft. (15 m) gas shielding hose.
- 50 ft. (15 m) weld cable.
- Quick disconnects for all cables.
- Weld contact switch.
- Cold wire inch switch.
- Wire direction switch.
- Pre and post flow controls.
- Wire reel adaptor for 30 lb. (14 kg) spools.
- Adjustable vertical and horizontal torch positioning system
- Rise and fall cam assembly with 5" (125 mm) of travel.
- Brushes and collector rings for welding current, rated at 300 AMPS 100% duty cycle.
- Brushes and collector rings for all controls, eliminates cable and hose wrap.

SET-UP AND OPERATION:

POWER SOURCE:

Use only constant voltage type power sources with this circle welder machine. If using a multiple process power source, be sure that it is set for constant voltage output as per the instructions in the manual for the power source. Set the power source polarity switch or properly connect the electrodes and work leads for the correct electrode polarity.

FIXTURING:

All circle welders have to be fixtured in some manner from the top of the shaft. This may be achieved in one of the following, column & boom, manipulator or carriage & monorail.

GUNS AND CABLES:

All circle welders come equipped with a gun and cable assembly. It is our recommendation that at least once a week the liner be taken out of the cable and soaked overnight in a solvent solution. To keep the wire moving it is also recommended that a felt clip be saturated with a product like Ferro Slick and feed thru the incoming tube of the wire feeder at least once a day.

SET-UP AND OPERATION CONTINUED:

ADDITIONAL CABLES:

The circle welders are supplied with the following cables:

1. CWO-3139 50' (15 m) power cable that connects the power source to the cable connector on the top gear of the machine.
2. CWO-3019 50' (15 m) weld cable that connects the lead coming out of the top of the machine using the quick connect connector to your power supply.
3. CWO-9406 50' (15 m) gas shielding hose that connects the gas fitting on the top of the shaft to your shielding gas supply.

WIRE SPEED AND VOLTAGE ADJUSTMENT:

The wire speed control on the front of the CWO-3332 Wire Feed Control box has a dial that is calibrated directly in inches per minute. Set the voltage using the control on the power source.

RISE AND FALL OF THE CAM:

All circle welders are equipped with a rise and fall cam assembly. The cam assembly must be aligned before any other settings can be made. To align the cam rotate the machine so the horizontal rack is parallel to the pipe, then adjust the gun holder so it is perpendicular to the horizontal rack. Position torch tip to top dead center of joint. Loosen the set screws in the brass block on the cam, and rotate the cam to the vertical position as shown. Refasten set screws.

CAM SETTING:



The cam setting is equal to distance "B" subtracted from distance "A".

Example:

Let A=3 and B=2

$3-2=1$

The cam setting is 1.



WHEEL ADJUSTMENT:


The CW-5 Racking System CWO-1670 and the Small Vertical Racker CWO-1685 are equipped with adjustable wheels. Always check these components for proper wheel adjustment before using the machine. The wheels need adjustment if you can cock or wiggle the components out of alignment. The wheels should be snug but not prohibit movement along the path of travel. The wheels with the hex stand offs are adjustable. To adjust the wheels, loosen the hex bolt (A) until the adjustable bushing (B) can be rotated. Correct the wheel alignment by rotating the adjustable bushing (B). Once adjusted, hold the adjustable bushing (B) while tightening the hex bolt (A). Recheck alignment.

MACHINE CONTROLS:

Operational parameters can be set using the two control boxes. Please refer to the sections in this manual entitled CWO-3332 Wire Feeder Control for descriptions of the various welding parameters that are available, as well as CWO-6110 Rotation Control for descriptions of the various speed and directional capabilities.


MAKING A WELD:

1. Position the gun to start position using the CWO-1670 Racking System.
2. Connect the ground cable to the workpiece. The ground cable must make good electrical contact with the work.
3. Position the electrode in the joint. The end of the electrode may be lightly touching the work.
4. With manual/auto switch in the "OFF" position, set rotation direction and speed.
5. Weld process and rotation are both started by throwing the manual/auto switch to auto.
6. Weld process and rotation are stopped by throwing the manual/auto switch to "OFF".



WARNING: When using an open arc process, it is necessary to use correct eye, head and body protection.

(CWO-3332) WIRE FEEDER CONTROLS



WIRE FEED SPEED CONTROL:

This control sets the feed speed of the wire feeder. Turn the knob to the left for slower speeds and to the right for higher speeds. The control is calibrated. The nameplate shows the wire speed for the given setting of the control.

WIRE DIRECTION:

Controls the direction the wire is being fed thru the feeder. **Up** to return wire to the spool. **Down** to feed the wire to the gun in order to weld.

MANUAL / AUTOMATIC:

The manual position allows the operator to rotate the machine without welding to check the wire placement as well as the cam setting. The auto side will start the entire weld operation based on the operators settings, including machine rotation.

PREFLOW CONTROL:

This control, provides flow of shielding gas to the work before the arc is established. The gas solenoid valve is energized immediately when the gun trigger is closed, but the time delay before the wire feeder is energized is adjustable from 0 to 1.5 seconds. Turn the knob to the left for shorter delays and to the right for longer delays.

POSTFLOW CONTROL:

This control provides flow of shielding gas to the work after welding has stopped. Delay for the gas solenoid valve shutoff is adjustable from .5 to 4.5 seconds. Turn the knob to the left for shorter delays and to the right for longer delays.


PURGE / COLD INCH SWITCH:

This control provides control of some wire feeder functions without energizing the welding power source. The momentary up position energizes the gas solenoid but not the wire feeder or welding power source. The momentary down position energizes the wire feeder but not the gas solenoid or the welding power source.

BURNBACK CONTROL:

This control provides a precise time delay that allows the wire to be burned off at the end of the weld. This is useful for those applications where higher speed, fine wire feeding is used and there is a tendency for the electrode to overrun at the end of the weld and cause "sticking" in the crater. The delay is adjustable for optimum burnback depending on wire size, process, procedure, etc.

(CWO-6110) ROTATION CONTROLS



SPEED CONTROL:

Controls the speed in which the machine travels. The depicted lines 0 to 100 should not be construed as inches per minute of travel. They should be considered as reference points only.

TRAVEL DIRECTION:

Controls the direction in which the machine will travel. Select the left arrow for clockwise rotation, brake for stop, and the right arrow for counterclockwise rotation.

ON/OFF SWITCH:

The on/off switch enables/disables power to the rotation control box.



PILOT LIGHT:

The pilot light indicates whether the machine is on/off as dictated by the on/off switch.

TECHNICAL DATA:

Amperage:	0-300 amps
Input Voltage:	115 VAC
Voltage:	0-50 VAC
Wire Sizes:	.035 - .062" (.8 - 1.6 mm)
Rotation Speed:	3-130 ipm (75-3300 mm/min)
Cam Range:	5" (125 mm)
Welding Diameter:	1 - 12" (25 - 300 mm)
Shielding Gas:	Solenoid Control
Height:	30" (762 mm)
Net Weight:	155 lbs. (71 kg)
Shipping Weight:	200 lbs. (91 kg)

DIMENSIONS:




CW-5 CIRCLE WELDER / PARTS LIST


ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BUG-1296	90 DEGREE HOSE ADAPTOR
2	1	CWO-3001	CW-5 SHAFT ASSEMBLY
3	1	CWO-1670	CW-5AX RACKING SYSTEM
4	1	CWO-1685	SMALL HORIZONTAL RACKER
5	1	CWO-2005	WIRE FEEDER GUARD
6	1	CWO-3004	CAM SHAFT & SPACER ASSEMBLY
7	1	CWO-3005	5" CAM ASSEMBLY
8	1	CWO-3008	WIRE REEL ASSEMBLY
9	1	CWO-3059	BRUSH HOLDER & SUPPORT ASSEMBLY
10	1	CWO-3199	CW-5 HOUSING ASSEMBLY
11	1	CWO-3275	WIRE FEEDER CONTROL MOUNT ASSEMBLY
12	1	CWO-3332	GMA WIRE FEED CONTROL
13	1	CWO-3384	P.M. MOTOR ASSEMBLY
14	1	CWO-3399	LOAD SPRING ASSEMBLY
15	1	CWO-3417	MOTOR & TRANSMISSION PLATE ASSMEBLY
16	1	CWO-3418	TRANSMISSION 3.5:1 ASSEMBLY
17	1	CWO-3456	CW-5 COLLECTOR
18	1	CWO-3462	SMALL BRUSH RETAINER ASSEMBLY
19	1	CWO-3466	SLIDE BAR MOUNTING ASSEMBLY
20	1	CWO-3468	LN-7 WIRE FEEDER ASSEMBLY
21	1	CWO-3935	TERMINAL BLOCK ASSEMBLY CW-5
22	1	CWO-4050	1" BEARING WITH FASTENERS
23	1	CWO-4060	1-1/4" BEARING WITH FASTENERS
24	1	CWO-4088	WIRE FEEDER MOUNT PLATE
25	1	CWO-4092	CABLE SUPPORT
26	1	CWO-5075	1-1/4" TRANTORQUE
27	1	CWO-5220	GUARD ASSEMBLY
28	1	CWO-5734	GEAR, ALUM (0716112) 2" BORE
29	1	CWO-6110	M-14 ROTATIONAL CONTROL ASSEMBLY
30	1	FAS-0376	HEX HD CAP SCR 5/16-18 X 5/8"

- NOTES:**
1. See CWO-1500-WD for wiring and cable information.
 2. CWO-3332 is shown with CWO-3332-K kit installed.
 3. CWO-6110 is shown with CWO-6110-K kit installed.

CW-5 CIRCLE WELDER / EXPLODED VIEW



CW-5 CIRCLE WELDER / WIRING DIAGRAM




ELECTRICAL COMPONENT CHART

ITEM	DESCRIPTION	PART NUMBER
1	Weld Cable Inlet 2/0	CWO-3012
2	Weld Cable	CWO-3013
3	Weld Cable 50'	CWO-3019
4	Large Brush Holder & Support	CWO-3059
5	Power Cable	CWO-3139*
6	GMA Pigtail	CWO-3331
7	GMA Wire Feeder Control	CWO-3332
8	P.M. Motor Assembly	CWO-3384
9	CW-5 Collector	CWO-3456
10	Small Brush Retainer Assembly	CWO-3462
11	LN-7 Wire Feeder Assembly	CWO-3468
12	Terminal Block	CWO-3935
13	M-14 Rotation Control	CWO-6110
14	Solonoid Adapter Kit	CWO-8056

*CWO-3139 Universal.


CWO-3139-M For Miller Welders.

(CWO-1670) CW-5 RACKING SYSTEM / EXPLODED VIEW / PARTS LIST



ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	ABR-1070	V-Guide Ways 19"
2	1	CWO-1675	Vertical Racker
3	1	CWO-1695	Attachment Block
4	1	CWO-3450	10.6# Load Spring Assy.
5	1	CWO-5544	Gun Clamp Assy.
6	2	FAS-1351	Hex Nut 1/4-20
7	2	FAS-2351	Hex Hd Cap Scr 1/4-20 x 1-1/4"

(CWO-1685) HORIZONTAL RACKER / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BUG-2032	Knob, Black
2	1	CWO-1671	Racker Shield
3	1	CWO-1678	Racker Plate
4	1	CWO-1679	Pinion 11T
5	2	CWO-1680	W2 Fixed Leg & Wheel Assy.
6	2	CWO-1681	W2 Adj. Leg & Wheel Assy.
7	1	CWO-1686	Mount Plate (Small Racker)
8	2	CWO-4020	Fixed Leg & Wheel Assy.
9	2	CWO-4021	Adj. Leg & Wheel Assy.
10	1	CWO-4112	Bracket
11	1	FAS-0355	Hex Hd Cap Scr 1/4-20 x 1/2"
12	2	FAS-0534	Soc Hd Cap Scr 10-24 x 3/8"
13	2	FAS-0557	Soc Hd Cap Scr 1/4-20 x 3/4"
14	2	FAS-0559	Soc Hd Cap Scr 1/4-20 x 1"
15	1	FAS-1307	Hex Jam Nut 3/4-16
16	1	FAS-1351	Hex Nut 1/4-20
17	1	MUG-1141	Bearing Collet
18	1	MUG-1142	Knob, Locking
19	1	MUG-1144	Shaft
20	2	MUG-1453	Stand-Off
21	1	MUG-1579	Retaining Ring
22	3	WAS-0240	1/4" SAE Washer
23	1	WAS-0243	1/4" Split Lock Washer

F = FIXED WHEEL PLACEMENT


A = ADJUSTABLE WHEEL PLACEMENT

(CWO-3001) SHAFT ASSEMBLY / EXPLODED VIEW




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BUG-9096	Outlet Bushing
2	2	CWO-4003	O-Ring
3	1	CWO-5781	CW-5 Shaft
4	1	CWO-5975	Plastic Bushing

(CWO-3004) CAM SHAFT AND SPACER ASSEMBLY / EXPLODED VIEW




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-4073	Ball Joint Rod End 5/16-24 RH
2	1	CWO-5019	Ball Joint Rod End 5/16-24 LH
3	1	CWO-9078	Spacer 1/2" O.D. x 5/16 I.D. x 3/4"
4	1	CWO-9357	Cam Shaft Tube
5	1	FAS-0377	Hex Hd Cap Scr 5/16-18x3/4"
6	1	FAS-1380	Hex Nut 5/16-24
7	1	FAS-1381	Hex Nut 5/16-24 LH
8	1	FAS-2375	Hex Hd Cap Scr 5/16-18x2"
9	3	WAS-0250	5/16 SAE Washer

(CWO-3005) 5" CAM ASSEMBLY / EXPLODED VIEW




ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	BUG-2098	Delrin Washer 3/8" I.D.
2	1	BUG-9012	Locking Coller
3	1	CWO-4026	Base Plate
4	2	CWO-4027	End Plate
5	1	CWO-4028	Center Block
6	1	CWO-4029	Screw
7	2	CWO-4031	Rod
8	1	CWO-4032	Knob
9	1	CWO-5199	Scale
10	4	FAS-0434	Set Scr 10-24x3/8"
11	1	FAS-0444	Set Scr 10-32x3/8"
12	2	FAS-0495	Set Scr 3/8-16x1/2"
13	4	FAS-0534	Soc Hd Cap 10-24x3/8"

(CWO-3008) WIRE REEL MOUNT ASSEMBLY / EXPLODED VIEW




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-5977	Vertical Mount Plate
2	1	CWO-3743	Horizontal Mount Plate
3	1	CWO-4081	Wire Reel Mount Bar
4	1	WFU-1041	2" O.D. Spindle Kit
5	4	FAS-2373	Hex Hd Cap Scr 5/16-18x1-1/2"
6	2	FAS-0559	Soc Hd Cap Scr 1/4-20x1"
7	2	FAS-1370	Hex Nut 5/16-18
8	4	WAS-0251	5/16 Lock Washer

(CWO-3059) LARGE BRUSH HOLDER AND SUPPORT / EXPLODED VIEW




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-4036	Large Brush Holder Support
2	1	CWO-4037	Attachment Bar
3	1	CWO-4046	Brush Holder For SE-4PT
4	2	CWO-4337	Brush
5	2	CWO-5548	Micarta Spacer
6	1	CWO-5549	Micarta Bushing
7	2	FAS-0305	Hex Hd Cap Scr 1/2-13x2"
8	1	FAS-0309	Hex Hd Cap Scr 1/2-13x1"
9	2	FAS-0357	Hex Hd Cap Scr 1/4-20x3/4"
10	2	WAS-0243	1/4" Lock Washer
11	1	WAS-0280	1/2" Washer
12	3	WAS-0281	1/2" Lock Washer

(CWO-3384) P.M. MOTOR ASSEMBLY #146 / EXPLODED VIEW



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-5691	P.M. Motor 146
2	1	CWO-4069	Gear, P.M. Motor 146
3	1	CWO-4147	P.M. Motor Bracket #970
4	3	TERM-WTE-1508	#8 Fork Blue 14RB-8FL T&B


(CWO-3332) GMA WIRE FEEDER CONTROL / EXPLODED VIEW



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BRK-WTE-1433	WTC-1015 LN-7 Switch
2	1	BUG-2255	Toggle Switch
3	2	BUG-2287	Power Receptacle
4	1	CON-0384	Cable Connector 2T Female
5	1	CON-WTE-1420	Cable Connector 6T Female
6	1	CWO-5461	Wire Feed Control Case
7	1	CWO-5462	Wire Feed Control Cover
8	1	CWO-5533A	Wire Feed Front Panel
9	1	CWO-5544B	Wire Feed Rear Panel
10	1	CWO-6335	Toggle Switch
11	4	FAS-0205	Rnd Hd Scr 4-40 x 1/2"
12	2	FAS-0215	Rnd Hd Scr 6-32 x 1/2"
13	4	FAS-1305	Hex Nut 4-40
14	6	FAS-1310	Hex Nut 6-32
15	1	LN7-WTE-1351	Motor Control Board
16	1	PCB-1350	Timing Control Board
17	2	POP-WTE-1435	Steel Rivet 1/8" x 1/4"
18	10	SCW-WTE-1435	Pan Hd Scr 6-32 x 1/4"
19	4	SCW-WTE-0481	Pan Hd Scr 6-32 x 1/2"
20	4	STOF-2009	Stand Off #6-32
21	1	SWT-0809	Toggle Switch
22	4	WAS-0201	#4 Internal Star Lock Washer
23	2	WAS-0211	#6 Internal Star Lock Washer

NOTE: ALL PARTS NOT CALLED OUT ARE COMPONENTS OF A LINCOLN ELECTRIC LN-7 GMA WIRE FEEDER. COMPONENT INFORMATION CAN BE FOUND IN THE LN-7 GMA WIRE FEEDER OPERATOR'S MANUAL.

(CWO-3332) GMA WIRE FEEDER CONTROL / WIRING DIAGRAM




ELECTRICAL COMPONENT CHART

ITEM	DESCRIPTION	PART NUMBER
1	Toggle Switch ON-Off-ON	BUG-2255
2	Power Receptical	BUG-2287
3	Panel Connector 2T-F	CON-0384
4	Toggle Switch ON-NONE-ON	CWO-6335
5	Timer Board	PCB-1350
6	Toggle Switch ON-NONE-ON	SWT-0809

--- = INDICATES CONTROL BOARD ITEMS THAT ARE NOT USER REPLACEABLE.


NOTE: ALL PARTS NOT CALLED OUT ARE COMPONENTS OF A LINCOLN ELECTRIC LN-7 GMA WIRE FEEDER. COMPONENT INFORMATION CAN BE FOUND IN THE LN-7 GMA WIRE FEEDER OPERATOR'S MANUAL.

(CWO-3418) TRANSMISSION 3.5:1 ASSEMBLY / EXPLODED VIEW




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-3276	Pinion Gear Assembly
2	1	CWO-4068	Transmission SW 3.5:1

(CWO-3462) SMALL BRUSH HOLDER ASSEMBLY / EXPLODED VIEW




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-3461	Small Retainer Block Assy.
2	1	CWO-9076	Retainer Support
3	2	FAS-0539	Soc Hd Cap Scr 10-24x1"
4	1	FAS-2351	Hex Hd Cap Scr 1/4-20x1/1/4"
5	1	WAS-0240	1/4" Washer
6	1	WAS-0243	1/4" Split Lock Washer
7	1	CWO-5626	Small Brush Retainer BLK
8	4	CWO-5831	Brush 1/8"x1/8"x7/8"
9	4	CWO-5874	Brush Holder
10	4	CWO-5875	Cap
11	4	CWO-5876	Clip
12	4	TERM-WTE-0602	#6 Fork Blue

(CWO-3461) SMALL RETAINER BLOCK ASSEMBLY / DETAIL VIEW




(CWO-6110) ROTATION CONTROL / EXPLODED VIEW



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	ARM-2279	Toggle Switch
2	1	BUG-9445	Power Cord
3	1	BUG-9687	Knob Fluted
4	1	BUG-9694	Knob
5	2	CSR-WTE-1597	Cord Strain Relieif
6	1	CWO-5547A	Rotation Box Front Panel
7	1	CWO-5547B	Rotation Box Rear Panel
8	1	CWO-6206	Indicator Light
9	1	CWO-6525	MTR Contorl Board w/Pot
10	1	CWO-6801	Rotation Control Case
11	1	CWO-6802	Rotation Box Cover
12	7	FAS-0115	#6-32 x 1/2" Pan Head Zinc
13	7	FAS-1310	Hex Nut 6-32
14	2	FHO-0188	Fuse Holder
15	1	FUS-0190	Fuse 1.5 Amp
16	1	FUS-0257	Fuse 3 Amp
17	1	MUG-1258-1	Rotary Switch Assembly
18	10	SCW-WTE-0264	#6-32 x 1/4" Sht Mt Scr
19	3	TERM-WTE-0439	#10 20 AWG Connector
20	7	WAS-0211	#6 Internal Star Washer
21	42	WRE-WTE-0501	18/3 SJO 300V Cord

(CWO-6110) ROTATION CONTROL / WIRING DIAGRAM



--- = INDICATES ITEMS THAT ARE SUPPLIED TOGETHER.


ELECTRICAL COMPONENT CHART

ITEM	DESCRIPTION	PART NUMBER
1	Toggle Switch	ARM-2279
2	Red Neon Lamp	CWO-6206
3	Speed Control Board w/Resistor	CWO-6525
4	Fuse 1.5 amp	FUS-0190
5	Fuse 3 amp	FUS-0257
6	Rotary Switch	MUG-1258-1

CW-5 GUN ASSEMBLIES

CWO-1500-A	#4 1/16 GUN ASSEMBLY MIG/FLUX	1/16 WIRE SIZE	
	CWO-8002	14H-116 CONTACTOR TIP	10
	CWO-8006	24A-62-SS NOZZLE	1
	CWO-8007	34A NOZZLE INSULATOR	1
	CWO-8008	54A GAS DEFUSER	1
	CWO-8011	44-116-15 CABLE LINER	1
	CWO-8523	40902 400 AMP CABLE	1
CWO-1500-B	#4 .035 GUN ASSEMBLY MIG/FLUX	.035 WIRE SIZE	
	CWO-8003	14H-35 CONTACTOR TIP	10
	CWO-8006	24A-62-SS NOZZLE	1
	CWO-8007	34A NOZZLE INSULATOR	1
	CWO-8008	54A GAS DEFUSER	1
	CWO-8009	44-3545-15 CABLE LINER	1
	CWO-8523	40902 400 AMP CABLE	1
CWO-1500-C	#4 .045 GUN ASSEMBLY MIG/FLUX	.045 WIRE SIZE	
	CWO-8004	14H-45 CONTACTOR TIP	10
	CWO-8006	24A-62-SS NOZZLE	1
	CWO-8007	34A NOZZLE INSULATOR	1
	CWO-8008	54A GAS DEFUSER	1
	CWO-8009	44-3545-15 CABLE LINER	1
	CWO-8523	40902 400 AMP CABLE	1
CWO-1500-D	#4 5/64 GUN ASSEMBLY MIG/FLUX	5/64 WIRE SIZE	
	CWO-8005	14H-564 CONTACTOR TIP	10
	CWO-8006	24A-62-SS NOZZLE	1
	CWO-8007	34A NOZZLE INSULATOR	1
	CWO-8008	54A GAS DEFUSER	1
	CWO-8012	44-564-15 CABLE LINER	1
	CWO-8523	40902 400 AMP CABLE	1
CWO-1500-E	#4 .052 GUN ASSEMBLY MIG/FLUX	.052 WIRE SIZE	
	CWO-8001	14H-52 CONTACT TIP	10
	CWO-8006	24A-62-SS NOZZLE	1
	CWO-8007	34A NOZZLE INSULATOR	1
	CWO-8008	54A GAS DEFUSER	1
	CWO-8011	44-116-15 CABLE LINER	1
	CWO-8523	40902 400 AMP CABLE	1

#4 GUN AND CABLE ASSEMBLY / EXPLODED VIEW / PARTS LIST




PARTS LIST				WIRE SIZE				
ITEM	QTY	PART #	DESCRIPTION	.035	.045	.052	1/16	5/64
1	1	CWO-8001	14H-52 Contact Tip			X		
1	1	CWO-8002	14H-116 Contact Tip				X	
1	1	CWO-8003	14H-35 Contact Tip	X				
1	1	CWO-8004	14H-45 Contact Tip		X			
1	1	CWO-8005	14H-564 Contact Tip					X
2	1	CWO-8006	24A-62-55 Nozzle	X	X	X	X	X
3	1	CWO-8007	34A Nozzle Insulator	X	X	X	X	X
4	1	CWO-8008	54A Gas Diffuser	X	X	X	X	X
5	1	CWO-8014	64A-60 Conductor Tube	X	X	X	X	X
6	2	CWO-8017	185 Case w/Binder Screws	X	X	X	X	X
7	2	CWO-8018	104 Cable Connector Block	X	X	X	X	X
8	1	CWO-8025	174 Connector Plug w/ O-Rings	X	X	X	X	X
9	1	CWO-8019	234-12 Cable Hose Support	X	X	X	X	X
10	1	CWO-8523	40902 400 AMP cable	X	X	X	X	X
*	1	CWO-8009	44-3545-15 Cable Liner	X	X			
*	1	CWO-8011	44-116-15 Cable Liner			X	X	
*	1	CWO-8012	44-564-15 Cable Liner					X

* ITEM NOT SHOWN

CW-5 DRIVE ROLL KITS


PART NUMBER	DESCRIPTION
CWO-7026-.035	DRIVE ROLL KIT .035 (0.9mm) SOLID WIRE
CWO-7026-.035C	DRIVE ROLL KIT .035 (0.9mm) CORED WIRE
CWO-7026-.052	DRIVE ROLL KIT .045-.052 (1.0-1.3mm) SOLID WIRE
CWO-7026-.052C	DRIVE ROLL KIT .045-.052 (1.0-1.3mm) CORED WIRE
CWO-7026-1/16	DRIVE ROLL KIT 1/16 (1.6mm) SOLID/CORED WIRE
CWO-7026-3/32	DRIVE ROLL KIT .068-3/32 (1.7-2.4mm) SOLID/CORED WIRE
CWO-7026-1/8	DRIVE ROLL KIT 7/64-1/8 (2.8-3.0mm) SOLID/CORED WIRE (REQUIRES MODIFICATIONS FOR 1/8" WIRE)

ACCESSORIES




CWO-3023-1 Torch Angle Adjuster

The Torch Angle Adjuster allows the operator to adjust the angle of the gun precisely, without unclamping the holding devise.




CWO-3778 Cycle Controller

The Cycle Controller eliminates the need for the operator to monitor the process and attempt to manually stop the machine at a desired spot. The Cycle Controller provides an adjustable, preset, auto-stop of the machines rotation and welding or cutting process.




CWO-1645 Mechanical Oscillator

The Mechanical Oscillator provides a pendulum-type motion to the gun. The speed and stroke of oscillation are adjustable.



CWO-3670 Step Adaptor


The Step Adaptor is a stepped centering device used to center the machine on threaded I.D. couplings. The range of the Step Adaptor is 1/2" to 4" (13-102 mm) diameter.



CWO-5790 Cone Adaptor

The Cone Adaptor is a tapered centering device used to center the machine on pipe stubbies. The range of the Cone Adaptor is 1-1/4" to 4" (32-102 mm) diameter.

ACCESSORIES




CWO-3894 HILLSIDE KIT

The CWO- 3894 Hillside Kit provides a *single* rise and fall motion per revolution of the machine to provide the motion required to follow the contour of an *offset* pipe-to-pipe weld.


During standard operation, the cam mechanism of all Cypress Welders provides a *dual* rise and fall action per revolution to follow the contour of a pipe-to-pipe weld. Once the Hillside kit is installed on a Cypress circle welder, the operator can easily engage or disengage it to switch between single or dual rise and fall operation.

CARRIAGES




CWO-4530 151 Carriage

The 151 Carriage mounts on a standard monorail. The carriage allows the operator to move the machine the length of the pipe, while utilizing a lever to position the machine vertically on the work piece.



CWO-4540 151P Carriage

The 151P Carriage mounts on a standard monorail. The carriage allows the operator to move the machine the length of the pipe, while utilizing a winch to position the machine vertically on the work piece.



CWO-4550 151M Carriage

The 151M Carriage mounts on a standard monorail, or "bridge crane" type setups. The carriage allows the operator to move the machine the length of the pipe, while utilizing an electric motor to mechanically position the machine vertically on the work piece.

SET-UP INSTRUCTIONS FOR CW-5 / CB-1P USED IN SPRINKLER FABRICATION.

SUPPORTING FIXTURE AND PIPE STANDS.

The first priority should be given to where the fixture is to be placed. The burning of the holes and welding of the couplings should be the last part of the operation performed on the pipe. It is important that a flow pattern or line be looked at, so that when the pipe is taken out of the fixture, it is finished and ready for shipment.

The mono rail consists of a 4" x 8" x 1/4" wall rectangular tubing with a 3/8" x 3" flat bar welded to the tubing (See pg. 27). The flat bar has to project 1" above the top of the tubing. "C" clamps are to be used to hold the flat bar against the tubing with no gaps. The "C" clamp may be walked down the tubing as it is being tack welded. If the beam has a bow in it, take the following steps:

1. Determine exactly where the center of the bow is. This may be accomplished by putting a string along the front side of the monorail. Place 1/2" nuts between the string and the monorail and measure the gap between the string and the monorail. Always measure on the same side of the string.
2. After you have determined where center of the bow is, take a hand torch and heat the outside of the bow. The outside of the bow should be the side the flat bar is welded to. Take a piece of chalk and draw a triangle with a 2" base under the bottom of the flat bar with the top or point of the triangle pointing down. Do the same on the top of the monorail against the flat bar with the top or point pointing towards the face of the monorail. Heat these two areas so that they become cherry red in color. After the heat has been applied, take a large rag and a bucket of water and cool the heated area. After the area has been cooled, check the beam again. Repeat as necessary.

PIPE STANDS

The pipe stands consist of 3" pipe in floor flanges with a 2-1/2" or 3" angle welded to the top of the pipe, and they should be spaced and aligned as shown (See pg. 27). The two stands should have some sort of clamping device to hold the pipe in place. The clamping device can be anything from a pipe vise to a chain and boom. The clamping device must be staggered.

After the pipe stands and supporting columns are in place, the monorail is to be placed on the supporting columns. The pipe stands and the supporting columns must be level and plumb. These items may have to be shimmed. With these items level, the monorail may be put in place on the supporting columns and held in place by two "C" clamps. Put a level on the face of the beam in the vertical position and on the bottom in the horizontal position. The beam should be level both ways, and if not, the beam will have to be shimmed. If the monorail has a twist, which may occur, level one end so that the other end needs to be pulled back.

Next, put a piece of 8" pipe in the pipe stands and clamp down. Take a center head and find the center of the pipe on each end and in the middle. You can now use two methods to check to see if the monorail is aligned with the pipe below. They are as follows:

1. Use a plumb bob off the face of the monorail and measure from the center of the pipe to the plumb bob. The distance should be 5-11/16" in all three locations.
2. The second method is to put one carriage on the monorail and attach the CB-1P to it. With the center pin in the burning machine, check all three locations. The burning machine must be plumb on the carriage if this method is used.

SET-UP INSTRUCTIONS FOR CW-5 / CB-1P USED IN SPRINKLER FABRICATION.

INSTALLING CARRIAGES AND MACHINES ON THE MONORAIL

Assemble carriages and put them on the rail.

The CW-5 welder is put on the carriage that is nearest to the welding power source and the CB-1P cutter nearest to the plasma power source.


Put the CB-1P cutter machine on the 8" pipe in the stands and bring the carriage to the machine. Lower the shaft coupling over the main shaft on the cutter. Ensure that shaft is fully inserted into the shaft coupling. Rotate the machine so that the plasma leads are in front and parallel to the carriage and tighten the set screws in the shaft coupling to secure the main shaft to the vertical slide assembly.

Next put the CW-5 welder on the 8" pipe and bring its carriage to it. Lower the shaft coupling down over the main shaft. Rotate the machine so that the welding lead on top of the machine will be on your left. This will put the electrical connector on the right. Tighten the set screws in the shaft coupling to secure the main shaft to the vertical slide assembly.


It is important for the machines to hang plumb. Left to right adjustments are made by loosening the two bolts that connect the shaft coupling to the vertical rail. Front to back adjustments are done by adjusting the position of the vertical rail support plate. Move the plate by adjusting the eight nuts on the four studs.

Note: Once machines are plumb verify that the machines are centered over the pipe stand.

CARRIAGE ADJUSTMENT:



SET-UP DIAGRAM FOR CW-5 / CB-1P USED IN SPRINKLER FABRICATION



PREVENTIVE MAINTENANCE / CW-5 CIRCLE WELDER

IMPORTANT: Make sure the input power at the power source is turned off and the 50' weld cable is disconnected from the circle welder prior to working inside the circle welder.

AFTER DAILY USE:

Refer to CW-5 Exploded View Parts List. (Pg. 10, 11)

Racking System item #3:

Inspect gear rack, hardened ways and wheels, remove all dirt, grease, weld spatter and rust. Check hardened ways for nicks and replace if necessary. Lubricate with a dry teflon or graphite spray lubricant. Adjust wheels for snug fit and smooth operation. Lubricate racker pinion with a dry teflon or graphite spray lubricant.

Small Vertical Racker item #4:

Inspect wheels and remove all dirt, grease, weld spatter and rust. Adjust wheels for snug fit and smooth operation. Lubricate racker pinion and wheels with a dry teflon or graphite spray lubricant.

Slide Bar Mounting Assembly item #18:

Inspect hardened ways remove all dirt, grease and weld spatter. Check hardened ways for nicks and replace if necessary. Lubricate with a dry teflon or graphite spray lubricant.

Refer to CW-5 Electrical Component Chart. (Pg. 12)

Power Cable item #5:

Inspect cable connector to make sure threads are not stripped and that the connector is not cracked. Check the cable for cuts, missing insulation and burn spots, replace if necessary.

CW-5 Collector Ring item #9:

Inspect cable connector to make sure threads are not stripped and that the connector is not cracked. Ensure that the connector is fastened properly to the large aluminum gear item #27 on the CW-5 Exploded View Parts List.

EVERY SIX MONTHS:

Refer to CW-5 Exploded View Parts List. (Pg. 10, 11)

Aluminum Gear item #27

Do not grease this gear. Inspect gear teeth remove all dirt, grease and weld spatter. Lubricate with a dry teflon or graphite spray lubricant. Replace gear if excessively worn.

P.M. Motor Assembly item #12:

Do not grease this pinion. Inspect the drive pinion. Remove all dirt, grease and weld spatter. Lubricate with a dry teflon or graphite spray lubricant. Replace pinion if excessively worn. Check set screw and tighten if necessary. Adjust motor assembly using the four adjustable mounting fasteners so that proper gear mesh is achieved between the aluminum gear item #27 and the motor drive pinion.

4" Cam Assembly item #6:

Inspect the slide rails and the cam pinion. Remove all dirt, grease and weld spatter. Do not grease slide rails or cam pinion. Lubricate with a dry teflon or graphite spray lubricant. Replace cam pinion if excessively worn. Tighten all fasteners as needed.

Wire Wheel Assembly item #7:

Periodically coat the wire wheel shaft with a thin layer of grease as needed. Inspect the shoe assembly and replace if excessively worn.

PREVENTIVE MAINTENANCE / CW-5 CIRCLE WELDER

Refer to CW-5 Electrical Component Chart. (Pg. 12)

GMA Wire Feed Control item #7:

Open control box, use an air hose to blow out dust and dirt. Check all wires for breaks and replace if necessary. Check all electrical connectors and plugs. If an electrical component fails refer to CWO-3332 Wire Feeder Control electrical component chart for replacement parts or return for service.

M-14 Rotation Control item #13:

Open control box use an air hose to blow out dust and dirt. Check all wires for breaks and replace if necessary. Check all electrical connectors and plugs. If an electrical component fails refer to CWO-6110 Rotation Control electrical component chart for replacement parts or return or service.

LN-7 Wire Feeder Assembly item #11:

Check brushes for wear. Brushes should be replaced when their length is less than 1/4 inch. Replace strain relief on wire if pulled out of motor housing.

Large Brush Holder & Support item #4:

Inspect brush holder. Make sure constant tension is being applied on the brushes. Brushes should move freely within the brush holder. Check brushes for arc build-up. If brushes are pitted they will need replaced. Remove the brushes and sand them to ensure a smooth contact surface. Make sure all fasteners are tight.

Small Brush Retainer Assembly item #10:

Inspect black brush holders for cracks and replace if needed. Check and make sure all wires are soldered properly to the holders. Replace the brushes when their length is less than 1/2 inch long. Remove the brushes and sand them to ensure a smooth contact surface. Make sure all fasteners are tight.

Terminal Block item #12:

Inspect the plastic terminal strip and make sure it is not cracked, replace if necessary. Make sure all terminal connections are tight. Make sure all ground wires are connected to the mounting screws of the terminal strip.

EVERY TWELVE MONTHS:

Refer to CW-5 Exploded View Parts List. (Pg. 10, 11)

1" Bearing With Fasteners item #21:

Do not grease the bearing, it is greased for life by the manufacturer. If the grease fitting has not been removed and plugged we suggest that you do so now. Earlier models may not have been plugged at time of assembly.

1-1/4" Bearing With Fasteners item #22:

Do not grease the bearing, it is greased for life by the manufacturer. If the grease fitting has not been removed and plugged we suggest that you do so now. Earlier models may not have been plugged at time of assembly.

P.M. Motor Assembly item #12:

Bodine gear motor lubrication. Fill gear motor to oil level indicator with worm gear oil conforming to AGMA#5EP compounded (SAE#90) oil or Bodine lubricant (#L-23). Do not overfill.

LN-7 Wire Feeder Assembly item #19:

Apply graphite grease to the gear teeth. Inspect the drive roll portion of the assembly, clean as necessary. Do not use solvents on the idle roll because it may wash the lubricant out of the bearings. Do not apply grease to the drive rolls.

Transmission 3.5:1 Assembly item #15:

Inspect for excessive wear and tear. Keep the transmission assembly clean and lubricate with Lubriplate #630-AA.

PREVENTIVE MAINTENANCE / CW-5 CIRCLE WELDER

Refer to CW-5 Electrical Component Chart. (Pg. 12)

CW-5 Collector item #9:

The collector ring should be sanded once a year. If the collector ring is pitted too badly it should be replaced. Inspect all wires coming out of the collector ring for cut or missing insulation. All wires should be fastened to the center shaft with a nylon cable tie. Tighten four set screws if needed.

Weld Cable Inlet 2/0 item #1:

Ensure that the cable is fastened tightly to the collector ring. Inspect the cable for cut or missing insulation. Make sure the micarta insulation tube on the cable is in good condition. Replace the cable if necessary.

Solenoid Adaptor Kit item #14:

Inspect for damage. Replace if necessary.

GMA Pigtail item #6:

Inspect the cable for cuts or missing insulation. Ensure that the elbow connector is not damaged. Ensure that all terminal ends are snug. Replace cable if necessary.