

INSTRUCTIONS AND PARTS MANUAL

CW-7 CIRCLE WELDER

Please record your equipment identification information below for future reference. This information can be found on your machine nameplate.

Model Number _____

Serial Number _____

Date of Purchase _____

Whenever you request replacement parts or information on this equipment, always supply the information you have recorded above.



CYPRESS WELDING EQUIPMENT INC.

CE

A DIVISION OF WELD TOOLING CORPORATION

3001 West Carson Street • Pittsburgh, PA USA 15204-1899

Telephone: 1-412-331-1776 • 1-800-245-3186 • Fax: 1-412-331-0383


<http://www.cypressweld.com>

PROTECT YOURSELF AND OTHERS FROM SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



ELECTRIC SHOCK can kill.

- 1) The equipment is not waterproof. Using the unit in a wet environment may result in serious injury. Do not touch equipment when wet or standing in a wet location.
- 2) The unused connectors have power on them. Always keep the unused connectors covered with the supplied protective panels. Operation of the machine without the protective panels may result in injury.
- 3) Never open the equipment without first unplugging the power cord or serious injury may result.
- 4) Verify the customer-supplied power connections are made in accordance with all applicable local and national electrical safety codes. If none exist, use International Electric Code (IEC) 950.
- 5) Never remove or bypass the equipment power cord ground. Verify the equipment is grounded in accordance with all applicable local and national electrical safety codes. If none exist, use International Electric Code (IEC) 950.



READ INSTRUCTIONS.

Read the instruction manual before installing and using the equipment.



EQUIPMENT DAMAGE POSSIBLE.

- 1) Do not plug in the power cord with out first verifying the equipment is OFF and the cord input voltage is the same as required by the machine or serious damage may result.
- 2) Always verify both the pinion and wheels are fully engaged before applying power or equipment damage may occur.
- 3) Do not leave the equipment unattended.
- 4) Remove from the worksite and store in a safe location when not in use.



FALLING EQUIPMENT can cause serious personal injury and equipment damage.

Faulty or careless user installation is possible. As a result, never stand or walk underneath equipment.



MOVING PARTS can cause serious injury.

- 1) Never try to stop the pinion from moving except by removing power or by using the STOP control.
- 2) Do not remove any protective panels, covers or guards and operate equipment.

HIGH FREQUENCY WARNINGS

SPECIAL PRECAUTIONS ARE REQUIRED WHEN USING PLASMA, TIG OR ANY WELDING PROCESS THAT USES HIGH FREQUENCY TO STRIKE AN ARC.



WARNING: HIGH FREQUENCY CAN EFFECT MACHINE OPERATION AND THEREFORE, WELD QUALITY.

Read the precautions below before installing and using the equipment.

PRECAUTIONS:

- 1) Some plasma or welding cables are strong sources of high frequency interference. NEVER lay a plasma or welding cable across the controls of the machine.
- 2) Always physically separate the plasma or welding cable leads from the machine cables. For example, the plasma or welding cable leads should NEVER be bundled with a pendant cable or the machine power cord. Maximize the separation between any machine cables and the plasma or welding cables.
- 3) Strictly follow the grounding procedures specified for the plasma or welding unit. NOTE: Some plasma and welding units produce exceptionally large amounts of high frequency noise. They may require a grounding rod be driven into the earth within six feet (2 meters) of the plasma or welding unit to become compatible with an automatic cutting or welding process.
- 4) If the high frequency is produced using a spark gap, adjust the points so the gap is as small as possible. The larger the gap, the higher the voltage and the higher the interference.
- 5) Some plasma or welding units will inject high frequency interference into the AC power line. Use separate power line branches whenever possible to power the plasma or welding source and the machine. Do not plug them into the same outlet box.
- 6) High frequency noise may enter the machine through the plasma or welding supply remote contactor leads. Some plasma and welding sources can produce noise spikes of up to several thousand volts. These sources are not compatible with automated cutting and welding equipment. It is recommended that the remote contactor leads on these plasma or welding sources not be connected to the machine. An alternate solution is to purchase a separate remote contactor isolation box.

CW-7 CIRCLE WELDER

INSTRUCTIONS AND PARTS MANUAL

TABLE OF CONTENTS

PAGE

5	Introduction / Features / Set-Up An Operation
7	CWO-3332 Wire Feeder Controls
8	CWO-6110 Rotation Controls
9	Technical Data / Dimensions
10	CW-7 Circle Welder / Parts List
11	CW-7 Circle Welder / Exploded View
12	CW-7 Circle Welder / Wiring Diagram / Electrical Component Chart
13	CWO-1665 CW-7 Racking System / Exploded View / Parts List
13	CWO-1690 Horizontal Racker / Exploded View / Parts List
14	CWO-2005 Wire Feeder Guard / Exploded View / Parts List
15	CWO-3027 Meter Kit Assembly / Exploded View / Parts List
15	CWO-3027 Meter Kit Assembly / Wiring Diagram
16	CWO-3496 Shaft Assembly / Exploded View / Parts List
16	CWO-3227 Cam Shaft & Spacer Assembly / Exploded View / Parts List
17	CWO-3205-11 7" Cam Assembly / Exploded View / Parts List
17	CWO-3498 5" Wire Reel Mount Assembly / Exploded View / Parts List
18	CWO-3063 Large Brush Holder & Support / Exploded View / Parts List
18	CWO-3194 Housing Assembly / Exploded View / Parts List
18	CWO-3361 P.M. Motor Assembly #147 / Exploded View / Parts List
19	CWO-3332 GMA Wire Feeder Control / Exploded View / Parts List
20	CWO-3332 GMA Wire Feeder Control / Wiring Diagram / Electrical Component Chart
21	CWO-3359 Transmission 5:1 Assembly / Exploded View / Parts List
21	CWO-3462 Small Brush Holder Assembly / Exploded View / Parts List
22	CWO-3490 CW-7 Flux Hopper Assembly / Exploded View / Parts List
23	CWO-6110 Rotation Control / Exploded View / Parts List
24	CWO-6110 Rotation Control / Wiring Diagram / Electrical Component Chart
25	CW-7 Gun Assemblies (MIG-FLUX)
27	CW-7 Gun Assemblies (SUB ARC)
28	#5 Gun & Cable Assembly / Exploded View / Parts List
29	CW-7 Drive Roll Kits
30	3- Jaw Expandable Chucks
31	Preventive Maintenance / CW-7 Circle Welder
34	Warranty

INTRODUCTION

The CW-7 Circle Welder is designed for welding of nozzles into vessels or domed heads utilizing SUB-ARC, MIG or FLUX CORED PROCESS, with gas shielding. The CW-7 mounts on a 3-Jaw Chuck welding diameter 6" to 50" O.D.

Features:

- Amperage & wire speed control.
- Wire feeder with one set of drive rolls.
- 1/12 HP P.M. motor and rotational speed control.
- 500 AMP gun & cable assembly.
- Gas shielding kit with 120 VAC solenoid valve.
- 5/8" (16 mm) gas cup.
- Burn back control.
- 50 ft. (15 m) power cable.
- 50 ft. (15 m) gas shielding hose.
- 50 ft. (15 m) weld cable.
- Quick disconnects for all cables.
- Weld contact switch.
- Cold wire inch switch.
- Wire direction switch.
- Pre and post flow controls.
- Wire reel adaptor for 60 lb. (27 kg) spools.
- Adjustable vertical and horizontal torch positioning system
- Rise and fall cam assembly with 7" (178 mm) of travel.
- Brushes and collector rings for welding current, rated at 500 AMPS 100% duty cycle.
- Brushes and collector rings for all controls, eliminates cable and hose wrap.

SET-UP AND OPERATION:

POWER SOURCE:

Use only constant voltage type power sources with this circle welder machine. If using a multiple process power source, be sure that it is set for constant voltage output as per the instructions in the manual for the power source. Set the power source polarity switch or properly connect the electrodes and work leads for the correct electrode polarity.

GUNS AND CABLES:

All circle welders come equipped with a gun and cable assembly. It is our recommendation that at least once a week the liner be taken out of the cable and soaked overnight in a solvent solution. To keep the wire moving it is also recommended that a felt clip be saturated with a product like Ferro Slick and feed thru the incoming tube of the wire feeder at least once a day.

SET-UP AND OPERATION CONTINUED:

ADDITIONAL CABLES:

The circle welders are supplied with the following cables:

1. CWO-3139 50' (15 m) power cable that connects the power source to the cable connector on the top gear of the machine.
2. CWO-3040 50' (15 m) weld cable that connects the lead coming out of the top of the machine using the quick connect connector to your power supply.
3. CWO-9406 50' (15 m) gas shielding hose that connects the gas fitting on the top of the shaft to your shielding gas supply.

WIRE SPEED AND VOLTAGE ADJUSTMENT:

The wire speed control on the front of the CWO-3332 Wire Feed Control box has a dial that is calibrated directly in inches per minute. Set the voltage using the control on the power source.

RISE AND FALL OF THE CAM:

All circle welders are equipped with a rise and fall cam assembly. The cam assembly must be aligned before any other settings can be made. To align the cam rotate the machine so the horizontal rack is parallel to the pipe, then adjust the gun holder so it is perpendicular to the horizontal rack. Position torch tip to top dead center of joint. Loosen the set screws in the brass block on the cam, and rotate the cam to the vertical position as shown. Refasten set screws.

CAM SETTING:



The cam setting is equal to distance "B" subtracted from distance "A".

Example:

Let A=3 and B=2


$$3-2=1$$

The cam setting is 1.



WHEEL ADJUSTMENT:

The CW-7 Racking System CWO-1665 and the Large Vertical Racker CWO-1690 are equipped with adjustable wheels. Always check these components for proper wheel adjustment before using the machine. The wheels need adjustment if you can cock or wiggle the components out of alignment. The wheels should be snug but not prohibit movement along the path of travel. The wheels with the hex stand offs are adjustable. To adjust the wheels, loosen the hex bolt (A) until the adjustable bushing (B) can be rotated. Correct the wheel alignment by rotating the adjustable bushing (B). Once adjusted, hold the adjustable bushing (B) while tightening the hex bolt (A). Recheck alignment.



MACHINE CONTROLS:


Operational parameters can be set using the two control boxes. Please refer to the sections in this manual entitled CWO-3332 Wire Feeder Control for descriptions of the various welding parameters that are available, as well as CWO-6110 Rotation Control for descriptions of the various speed and directional capabilities.

MAKING A WELD:

1. Position the gun to start position using the CWO-1665 Racking System.
2. Connect the ground cable to the workpiece. The ground cable must make good electrical contact with the work.
3. Position the electrode in the joint. The end of the electrode may be lightly touching the work.
4. With manual/auto switch in the "OFF" position, set rotation direction and speed.
5. Weld process and rotation are both started by throwing the manual/auto switch to auto.
6. Weld process and rotation are stopped by throwing the manual/auto switch to "OFF".

WARNING: When using an open arc process, it is necessary to use correct eye head and body protection.

(CWO-3332) WIRE FEEDER CONTROLS



WIRE FEED SPEED CONTROL:

This control sets the feed speed of the wire feeder. Turn the knob to the left for slower speeds and to the right for higher speeds. The control is calibrated. The nameplate shows the wire speed for the given setting of the control.

WIRE DIRECTION:

Controls the direction the wire is being fed thru the feeder. **Up** to return wire to the spool. **Down** to feed the wire to the gun.

MANUAL / AUTOMATIC:

The manual position allows the operator to rotate the machine without welding to check the wire placement as well as the cam setting. The auto side will start the entire weld operation based on the operators settings, including machine rotation.

PREFLOW CONTROL:

This control, provides flow of shielding gas to the work before the arc is established. The gas solenoid valve is energized immediately when the gun trigger is closed, but the time delay before the wire feeder is energized is adjustable from 0 to 1.5 seconds. Turn the knob to the left for shorter delays and to the right for longer delays.

POSTFLOW CONTROL:

This control provides flow of shielding gas to the work after welding has stopped. Delay for the gas solenoid valve shutoff is adjustable from .5 to 4.5 seconds. Turn the knob to the left for shorter delays and to the right for longer delays.


PURGE / COLD INCH SWITCH:

This control provides control of some wire feeder functions without energizing the welding power source. The momentary up position energizes the gas solenoid but not the wire feeder or welding power source. The momentary down position energizes the wire feeder but not the gas solenoid or the welding power source.

BURNBACK CONTROL:

This control provides a precise time delay that allows the wire to be burned off at the end of the weld. This is useful for those applications where higher speed, fine wire feeding is used and there is a tendency for the electrode to overrun at the end of the weld and cause "sticking" in the crater. The delay is adjustable for optimum burnback depending on wire size, process, procedure, etc.

(CWO-6110) ROTATION CONTROLS



SPEED CONTROL:

Controls the speed in which the machine travels. The depicted lines 0 to 100 should not be construed as inches per minute of travel. They should be considered as reference points only.

TRAVEL DIRECTION:

Controls the direction in which the machine will travel. Select forward for clockwise rotation, brake for stop, and reverse for counterclockwise rotation.

ON/OFF SWITCH:

The on/off switch enables/disables power to the rotation control box.


PILOT LIGHT:

The pilot light indicates whether the machine is on/off as dictated by the on/off switch.

TECHNICAL DATA:

Amperage:	0-500 amps
Input Voltage:	115 VAC
Voltage:	0-50 VAC
Wire Sizes:	.035-.094" (.8-2.4 mm)
Rotation Speed:	4-137 ipm (75-3500 mm/min)
Cam Range:	0"-7" (0-175 mm)
Welding Radius:	6"-24" (150-600 mm)
Shielding Gas:	Solenoid Control
Height:	34" (864 mm)
Net Weight:	250 lbs. (113.6 kg)
Shipping Weight:	380 lbs. (173.0 kg)

DIMENSIONS:




CW-7 CIRCLE WELDER / PARTS LIST

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-1665	CW-7 Racking System
2	1	CWO-1690	Large Horizontal Racker
3	1	CWO-2005	Wire Feed Guard
4	1	CWO-3027	Meter Kit Assembly
5	1	CWO-3063	Brush Holder & Support Assy.
6	1	CWO-3194	CW-7 Housing Assy.
7	1	CWO-3204	Slide Bar Mounting Assy.
8	1	CWO-3205-11	7" Cam Assy.
9	1	CWO-3218	Cable Support Bar
10	1	CWO-3227	Camshaft & Bar Assy.
11	1	CWO-3287	Base Plate
12	1	CWO-3288	Motor & Transmission Plate Assy.
13	1	CWO-3312	Lifting Lug Assy.
14	1	CWO-3332	GMA Wire Feed Assy.
15	1	CWO-3359	Transmission SW 5:1 Assy.
16	1	CWO-3361	P.M. Motor Assy. #147
17	1	CWO-3462	Small Brush Retainer Assy.
18	1	CWO-3468	LN-7 Wire Feeder Assy.
19	1	CWO-3478	Weld Cable 3/0
*20	1	CWO-3490	CW-7 Flux Hopper Assy.
21	1	CWO-3492	CW-7 Collector
22	1	CWO-3493	Weld Cable Inlet 3/0
23	1	CWO-3496	Shaft Assy., CW-7 AB, ABG
24	1	CWO-3498	Wire Reel Assy.
25	1	CWO-3499	CW-7 Guard Assy.
26	1	CWO-3935	Terminal Block Assy.
27	1	CWO-4088	Wire Feeder Mount Plate
28	2	CWO-4340	1-1/2" Flange Bearing
29	1	CWO-4900	33# Load Spring Assy.
30	1	CWO-5074	1-1/2" I.D. Trantorque
31	1	CWO-5735	10" Diameter Aluminum Gear
32	1	CWO-6110	M-14 Rotational Control
33	1	CWO-6416	Control Mount Plate
34	1	CWO-8057	Solenoid Adaptor Kit


- Notes:**
1. See CWO-1700-WD for wiring and cable information.
 2. CWO-3332 is shown with CWO-3332-K kit installed.
 3. CWO-6110 is shown with CWO-6110-K kit installed.

* CWO-3490 CW-7 Flux Hopper Assembly are installed on Sub-Arc models only.

(CWO-1700) CW-7 CIRCLE WELDER / EXPLODED VIEW



CW-7 CIRCLE WELDER / WIRING DIAGRAM




ELECTRICAL COMPONENT CHART

ITEM	DESCRIPTION	PART NUMBER
1	Meter Kit Assembly	CWO-3027
2	Weld Cable 4/0 50 ft.	CWO-3040
3	Brush Holder & Support Assy.	CWO-3063
4	Power Cable	CWO-3139*
5	GMA Pigtail	CWO-3331
6	GMA Wire Feed Control	CWO-3332
7	P.M. Motor Assy.	CWO-3361
8	Small Brush Retainer Assy.	CWO-3462
9	LN-7 Wire Feeder Assy.	CWO-3468
10	Weld Cable 3/0	CWO-3478
11	CW-7 Collector	CWO-3492
12	Weld Cable Inlet 3/0	CWO-3493
13	CW-5 Terminal Block	CWO-3935
14	Shunt Bar 500-50	CWO-6008
15	M-14 Rotational Control	CWO-6110
16	Solenoid Adaptor Kit	CWO-5057

*CWO-3139 For Universal Welders


CWO-3139-M For Miller Welders.

(CWO-1665) CW-7 RACKING SYSTEM / EXPLODED VIEW / PARTS LIST



ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	ABR-1060	V-Guide Ways 33"
2	1	CWO-1675	Vertical Racker
3	1	CWO-1695	Attachment Block
4	1	CWO-3023-1	Torch Angle Adjuster 16"
5	1	CWO-3460	24.8# Load Spring Assy.

(CWO-1690) HORIZONTAL RACKER / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BUG-2032	Knob, Black
2	1	CWO-1671	Racker Shield
3	1	CWO-1678	Racker Plate
4	1	CWO-1679	Pinion 11T
5	2	CWO-1680	W2 Fixed Leg & Wheel Assy.
6	2	CWO-1681	W2 Adj. Leg & Wheel Assy.
7	1	CWO-1687	Mount Plate (Large Racker)
8	2	CWO-4326	Fixed Leg & Wheel Assy.
9	2	CWO-4327	Adj. Leg & Wheel Assy.
10	2	FAS-0557	Soc Hd Cap Scr 1/4-20 x 3/4"
11	1	FAS-1307	Hex Jam Nut 3/4-16
12	1	MUG-1141	Bearing Collet
13	1	MUG-1142	Knob, Locking
14	1	MUG-1144	Shaft
15	2	MUG-1453	Stand-Off
16	1	MUG-1579	Retaining Ring
17	2	WAS-0240	1/4" SAE Washer
18	2	FAS-0559	Soc Hd Cap Scr 1/4-20 x 1"

F = FIXED WHEEL PLACEMENT

A = ADJUSTABLE WHEEL PLACEMENT

(CWO-2005) WIRE FEEDER GUARD / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BUG-3209	Hinge 3/4" x 2" LG
2	1	CWO-2008	Plastic Guard
3	2	FAS-0534	Soc Hd Cap 10-24 x 3/8"
4	2	FAS-0535	Soc Hd Cap 10-24 x 1/2"
5	2	FAS-1330	Hex Nut 10-24
6	2	WAS-0230	#10 Washer


(CWO-3027) METER KIT ASSEMBLY / EXPLODED VIEW / PARTS LIST

ITEM	QTY	PART NUMBER	DESCRIPTION
1	48"	900-4-001	2 Cond. 18 AWG. SJO Cord
2	1	CSR WTE 0187	Wire Strain Relief
3	1	CWO-4396	DC Volt Meter, 0-50 VDC
4	1	CWO-4397	DC AMP Meter, 0-500 ADC
5	1	CWO-4399	5" x 7" Front Meter Plate
6	1	CWO-6374	Alum. Box, Powder Coated
7	1	FAS-0145	Pan Hd Scr #10-32 x 1/2"
8	1	FAS-1340	Hex Nut #10-32
9	4	FAS-2935	Sheet Metal Scr #6 x 3/8"
10	5	TERM WTE 0294	#10 Ring, Red
11	3	TERM-0024	1/4" Red Ring
12	1	TERM-4162	1/4" Blue Ring
13	1	WAS-0231	#10 Internal Star Washer

(CWO-3027) METER KIT ASSEMBLY / WIRING DIAGRAM




(CWO-3496) SHAFT ASSEMBLY / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BUG-9096	Outlet Bushing, Oxygen
2	2	CWO-4049	O-Ring, Oxygen, Fuel
3	1	CWO-5778	Shaft CW-7AG / CW-7ABG

(CWO-3227) CAM SHAFT & SPACER ASSEMBLY / EXPLODED VIEW / PARTS LIST

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-4352	Ball Joint Rod End 3/8-24 RH
2	1	CWO-5042	Ball Joint Rod End 3/8-24 LH
3	1	CWO-9081	Spacer / CW-7
4	1	CWO-9355	Pipe / Cam Shaft CW-7
5	1	FAS-0399	Hex Hd Cap Scr 3/8-16 x 1"
6	1	FAS-1395	3/8-24 Hex Jam Nut - RH
7	1	FAS-1396	3/8-24 Hex Jam Nut - LH
8	1	FAS-2396	Hex Hd Cap Scr 3/8-16 x 2-1/4"
9	3	WAS-0260	3/8" SAE Washer




(CWO-3205-11) 7" CAM ASSEMBLY / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	BUG-2098	Delrin Washer 3/8"
2	1	BUG-9012	Locking Collar
3	2	CWO-4027	End Plate
4	1	CWO-4028	Center Plate
5	1	CWO-4032	Knob
6	1	CWO-4328	Base Plate
7	1	CWO-4331	Screw
8	2	CWO-4332	Rod
9	1	CWO-5199	Scale
10	4	FAS-0434	Set Scr #10-24x3/8"
11	1	FAS-0444	Set Scr #10-32x3/8"
12	2	FAS-0495	Set Scr 3/8"-16x1/2"
13	4	FAS-0534	Soc Hd Cap Scr #10-24x3/8"


(CWO-3498) 5" WIRE REEL MOUNT ASSEMBLY / EXPLODED VIEW / PARTS LIST



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BUG-3293	Reel, 60 lbs.
2	1	CWO-3217	Wire Reel Support Assy.
3	2	FAS-1301	Hex Nut 1/2-13
4	2	FAS-2305	Hex Hd Cap Scr 1/2-13 x 1-3/4"
5	2	WAS-0281	1/2" Lock Washer




(CWO-3063) LARGE BRUSH HOLDER AND SUPPORT / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-4036	Large Brush Holder Support (P)
2	2	CWO-4046	Large Brush Holder (P)
3	4	CWO-4337	Brush
4	1	CWO-4339	Attachment Bar 4.375" Long
5	2	CWO-5548	Micarta Spacer
6	1	CWO-5549	Micarta Bushing
7	1	FAS-0304	Hex Hd Cap Scr 1/2-13 x 3.5"
8	1	FAS-0305	Hex Hd Cap Scr 1/2-13 x 2"
9	1	FAS-0309	Hex Hd Cap Scr 1/2-13 x 1"
10	1	FAS-0357	Hex Hd Cap Scr 1/4-20 x 3/4"
11	2	FAS-0359	Hex Hd Cap Scr 1/4-20 x 1"
12	3	WAS-0243	1/4" Lock Washer
13	2	WAS-0280	1/2" Washer
14	3	WAS-0281	1/2" Lock Washer

(CWO-3194) HOUSING ASSEMBLY / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-4133	1/4-18 x 1/2" NPSM Hex HD Plug, Brass
2	1	CWO-5841	Center Tube Housing CW-7
3	1	CWO-5844	Top Housing Plate CW-7
4	1	CWO-5847	Lower Housing Plate CW-7
5	2	CWO-5973	Plastic Bushing
6	3	CWO-9339	Angle For Guard
7	3	FAS-0535	Soc Hd Cap Scr 10-24 x 1/2"
8	8	FAS-0548	Soc Hd Cap Scr 10-32 x 3/4"

(CWO-3361) P.M. MOTOR ASSEMBLY #147 / EXPLODED VIEW / PARTS LIST



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-4067	P.M. Motor #147
2	1	CWO-4147	P.M. Motor Bracket #970
3	1	CWO-5767	Gear, P.M. Motor #147
4	1	FAS-0454	Set Scr 1/4-20x3/8"
5	3	TER-WTE-1508	#8 Fork Blue 14RB-8FL-T&B


(CWO-3332) GMA WIRE FEEDER CONTROL / EXPLODED VIEW / PARTS LIST



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	BRK-WTE-1433	WTC-1015 LN-7 Switch
2	1	BUG-2255	Toggle Switch
3	2	BUG-2287	Power Receptacle
4	1	CON-0384	Cable Connector 2T Female
5	1	CON-WTE-1420	Cable Connector 6T Female
6	1	CWO-5461	Wire Feed Control Case
7	1	CWO-5462	Wire Feed Control Cover
8	1	CWO-5533A	Wire Feed Front Panel
9	1	CWO-5544B	Wire Feed Rear Panel
10	1	CWO-6335	Toggle Switch
11	4	FAS-0205	Rnd Hd Scr 4-40 x 1/2"
12	2	FAS-0215	Rnd Hd Scr 6-32 x 1/2"
13	4	FAS-1305	Hex Nut 4-40
14	6	FAS-1310	Hex Nut 6-32
15	1	LN7-WTE-1351	Motor Control Board
16	1	PCB-1350	Timing Control Board
17	2	POP-WTE-1435	Steel Rivet 1/8" x 1/4"
18	10	SCW-WTE-1435	Pan Hd Scr 6-32 x 1/4"
19	4	SCW-WTE-0481	Pan Hd Scr 6-32 x 1/2"
20	4	STOF-2009	Stand Off #6-32
21	1	SWT-0809	Toggle Switch
22	4	WAS-0201	#4 Internal Star Lock Washer
23	2	WAS-0211	#6 Internal Star Lock Washer

NOTE: ALL PARTS NOT CALLED OUT ARE COMPONENTS OF A LINCOLN ELECTRIC LN-7 GMA WIRE FEEDER. COMPONENT INFORMATION CAN BE FOUND IN THE LN-7 GMA WIRE FEEDER OPERATOR'S MANUAL.

(CWO-3332) GMA WIRE FEEDER CONTROL / WIRING DIAGRAM




ELECTRICAL COMPONENT CHART

ITEM	DESCRIPTION	PART NUMBER
1	Toggle Switch ON-Off-ON	BUG-2255
2	Power Receptacle	BUG-2287
3	Panel Connector 2T-F	CON-0384
4	Toggle Switch ON-NONE-ON	CWO-6335
5	Timer Board	PCB-1350
6	Toggle Switch ON-NONE-ON	SWT-0809

--- = INDICATES CONTROL BOARD ITEMS THAT ARE NOT USER REPLACEABLE.


NOTE: ALL PARTS NOT CALLED OUT ARE COMPONENTS OF A LINCOLN ELECTRIC LN-7 GMA WIRE FEEDER. COMPONENT INFORMATION CAN BE FOUND IN THE LN-7 GMA WIRE FEEDER OPERATOR'S MANUAL.

(CWO-3359) TRANSMISSION 5:1 ASSEMBLY / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-4347	Transmission 5:1
2	4	FAS-0359	Hex Hd Cap Scr 1/4-20x1"
3	4	FAS-1351	1/4-20 Hex Nut
4	4	WAS-0240	1/4" SAE Washer
5	4	WAS-0243	1/4" Lock Washer
6	1	UNI-1024	Slave Pinion

(CWO-3462) SMALL BRUSH HOLDER ASSEMBLY / EXPLODED VIEW / PARTS LIST




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-3461	Small Retainer Block Assy.
2	1	CWO-9076	Retainer Support
3	2	FAS-0539	Soc Hd Cap Scr 10-24x1"
4	1	FAS-2351	Hex Hd Cap Scr 1/4-20x1 1/4"
5	1	WAS-0240	1/4" Washer
6	1	WAS-0243	1/4" Split Lock Washer
7	1	CWO-5626	Small Brush Retainer BLK
8	4	CWO-5831	Brush 1/8"x1/8"x7/8"
9	4	CWO-5874	Brush Holder
10	4	CWO-5875	Cap
11	4	CWO-5876	Clip
12	4	TERM-WTE-0602	#6 Fork Blue

(CWO-3461) SMALL RETAINER BLOCK ASSEMBLY / DETAIL VIEW




(CWO-3490) CW-7 FLUX HOPPER ASSEMBLY / EXPLODED VIEW / PARTS LIST

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CWO-3757	Hopper Support Rod
2	1	CWO-3760	Clamp Block 1/2"
3	1	CWO-3478	3/4" Hose Barb
4	1	CWO-3769	Flux Hopper Steel 12"
5	1	GOF-3019	Handle w/Bolts
N/S	48"	1000-4-001	3/4" ID x 1" OD Clear Hose




(CWO-6110) ROTATION CONTROL / EXPLODED VIEW / PARTS LIST



ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	ARM-2279	Toggle Switch
2	1	BUG-9445	Power Cord
3	1	BUG-9687	Knob Fluted
4	1	BUG-9694	Knob
5	2	CSR-WTE-1597	Cord Strain Relief
6	1	CWO-5547A	Rotation Box Front Panel
7	1	CWO-5547B	Rotation Box Rear Panel
8	1	CWO-6206	Indicator Light
9	1	CWO-6525	MTR Control Board w/Pot
10	1	CWO-6801	Rotation Control Case
11	1	CWO-6802	Rotation Box Cover
12	7	FAS-0115	#6-32 x 1/2" Pan Head Zinc
13	7	FAS-1310	Hex Nut 6-32
14	2	FHO-0188	Fuse Holder
15	1	FUS-0190	Fuse 1.5 Amp
16	1	FUS-0257	Fuse 3 Amp
17	1	MUG-1258-1	Rotary Switch Assembly
18	10	SCW-WTE-0264	#6-32 x 1/4" Sht Mt Scr
19	3	TERM-WTE-0439	#10 20 AWG Connector
20	7	WAS-0211	#6 Internal Star Washer
21	42	WRE-WTE-0501	18/3 SJO 300V Cord
22	1	CWO-6524	Pot

(CWO-6110) ROTATION CONTROL / WIRING DIAGRAM



--- = INDICATES ITEMS THAT ARE SUPPLIED TOGETHER.

ELECTRICAL COMPONENT CHART

ITEM	DESCRIPTION	PART NUMBER
1	Toggle Switch	ARM-2279
2	Red Neon Lamp	CWO-6206
3	Speed Control Board w/Resistor	CWO-6525
4	Fuse 1.5 amp	FUS-0190
5	Fuse 3 amp	FUS-0257
6	Rotary Switch	MUG-1258-1

CW-7 GUN ASSEMBLIES (MIG/FLUX-CORED)

CWO-1560-A	#5 .035 GUN ASSEMBLY MIG/FLUX	.035 WIRE SIZE	
	CWO-8027	15H-35 CONTACT TIP	10
	CWO-8034	25CT-75 NOZZLE	1
	CWO-8035	35CT NOZZLE INSULATOR	1
	CWO-8036	55 SW GAS DIFFUSER	1
	CWO-8039	45-3545-15 CABLE LINER	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1560-B	#5 .045 GUN ASSEMBLY MIG/FLUX	.045 WIRE SIZE	
	CWO-8028	15H-45 CONTACT TIP	10
	CWO-8034	25CT-75 NOZZLE	1
	CWO-8035	35CT NOZZLE INSULATOR	1
	CWO-8036	55 SW GAS DIFFUSER	1
	CWO-8039	45-3545-15 CABLE LINER	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1560-C	#5 1/16 GUN ASSEMBLY MIG/FLUX	1/16 WIRE SIZE	
	CWO-8029	15H-116 CONTACT TIP	10
	CWO-8034	25CT-75 NOZZLE	1
	CWO-8035	35CT NOZZLE INSULATOR	1
	CWO-8037	55 GAS DIFFUSER	1
	CWO-8041	45-116-15 CABLE LINER	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1560-D	#5 5/64 GUN ASSEMBLY MIG/FLUX	5/64 WIRE SIZE	
	CWO-8031	15H-564 CONTACT TIP	10
	CWO-8034	25CT-75 NOZZLE	1
	CWO-8035	35CT NOZZLE INSULATOR	1
	CWO-8038	55 GAS DIFFUSER	1
	CWO-8085	45-564-15 CABLE LINER	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1560-E	#5 3/32 GUN ASSEMBLY MIG/FLUX	3/32 WIRE SIZE	
	CWO-8032	15H-332 CONTACT TIP	10
	CWO-8034	25CT-75-NOZZLE	1
	CWO-8035	35CT NOZZLE INSULATOR	1
	CWO-8042	45H-332-15 CABLE LINER	1
	CWO-8038	55H-GAS DIFFUSER	1
	CWO-8524	50394 500 AMP CABLE	1


CW-7 GUN ASSEMBLIES (MIG/FLUX-CORED)

CWO-1560-F	#5 1/8 GUN ASSEMBLY MIG/FLUX	1/8 WIRE SIZE	
	CWO-8033	15H-18 CONTACT TIP	10
	CWO-8034	25CT-75-NOZZLE	1
	CWO-8035	35CT NOZZLE INSULATOR	1
	CWO-8043	45-18-15 CABLE LINER	1
	CWO-8038	55H-GAS DIFFUSER	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1560-G	#5 .052 GUN ASSEMBLY MIG/FLUX	.052 WIRE SIZE	
	CWO-8024	15H-52 CONTACT TIP	10
	CWO-8034	25CT-75 NOZZLE	1
	CWO-8035	35CT NOZZLE INSULATOR	1
	CWO-8036	55 SW GAS DIFFUSER	1
	CWO-8041	45-116-15 CABLE LINER	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1560-H	#5 7/64 GUN ASSEMBLY MIG-FLUX	7/64 WIRE SIZE	
	CWO-8022	15H-764 CONTACT TIP	10
	CWO-8034	25CT-75 NOZZLE	1
	CWO-8035	35CT NOZZLE INSULATOR	1
	CWO-8038	55 H GAS DIFFUSER	1
	CWO-8044	45H-764-15 CABLE LINER	1
	CWO-8524	50394 500 AMP CABLE	1

CW-7 GUN ASSEMBLIES (SUB ARC)

CWO-1700-A	#5 .035 GUN ASSEMBLY SUB ARC	.035 WIRE SIZE	
	CWO-8027	15H-35 CONTACT TIP	10
	CWO-8036	55 SW GAS DIFFUSER	1
	CWO-8039	45-3545-15 CABLE LINER	1
	CWO-8054	25-SA NOZZLE FLUX CONE	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1700-B	#5 .045 GUN ASSEMBLY SUB ARC	.045 WIRE SIZE	
	CWO-8028	15H-45 CONTACT TIP	10
	CWO-8036	55 SW GAS DIFFUSER	1
	CWO-8039	45-3545-15 CABLE LINER	1
	CWO-8054	25-SA NOZZLE FLUX CONE	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1700-C	#5 1/16 GUN ASSEMBLY SUB ARC	1/16 WIRE SIZE	
	CWO-8029	15H-116 CONTACT TIP	10
	CWO-8037	55 GAS DIFFUSER	1
	CWO-8041	45-116-15 CABLE LINER	1
	CWO-8054	25-SA NOZZLE FLUX CONE	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1700-D	#5 5/64 GUN ASSEMBLY SUB ARC	5/64 WIRE SIZE	
	CWO-8031	15H-564 CONTACT TIP	10
	CWO-8038	55 GAS DIFFUSER	1
	CWO-8042	45-116-15 CABLE LINER	1
	CWO-8054	25-SA NOZZLE FLUX CONE	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1700-E	#5 3/32 GUN ASSEMBLY SUB ARC	3/32 WIRE SIZE	
	CWO-8032	15H-332 CONTACT TIP	10
	CWO-8038	55H-GASS DIFFUSER	1
	CWO-8042	45-332-15 LINER	1
	CWO-8054	25-SA NOZZLE FLUX CONE	1
	CWO-8524	50394 500 AMP CABLE	1
CWO-1700-G	#5 .052 GUN ASSEMBLY SUB ARC	.052 WIRE SIZE	
	CWO-8024	15H-52 CONTACT TIP	10
	CWO-8036	55 SW GAS DIFFUSER	1
	CWO-8041	45-116-15 CABLE LINER	1
	CWO-8054	25-SA NOZZLE FLUX CONE	1
	CWO-8524	50394 500 AMP CABLE	1

#5 GUN AND CABLE ASSEMBLY / EXPLODED VIEW / PARTS LIST



PARTS LIST				WIRE SIZE							
ITEM	QTY	PART #	DESCRIPTION	.035	.045	.052	1/16	5/64	3/32	7/64	1/8
1	1	CWO-8022	15H-764 Contact Tip							X	
1	1	CWO-8024	15H-52 Contact tip			X					
1	1	CWO-8027	15H-Contact Tip	X							
1	1	CWO-8028	15H-45 Contact Tip		X						
1	1	CWO-8029	15H-116 Contact Tip				X				
1	1	CWO-8031	15H-564 Contact Tip					X			
1	1	CWO-8032	15H-332 Contact Tip						X		
1	1	CWO-8033	15H-18 Contact Tip								X
2	1	CWO-8034	25CT-75 Nozzle Insulator	X	X	X	X	X	X	X	X
3	1	CWO-8035	35CT Nozzle Insulator	X	X	X	X	X	X	X	X
4	1	CWO-8036	55SW Gas Diffuser	X	X	X					
4	1	CWO-8037	55 Gas Diffuser				X				
4	1	CWO-8038	55H Gas Diffuser					X	X	X	X
5	1	CWO-8045	65-60 Conductor Tube	X	X	X	X	X	X	X	X
6	2	CWO-8017	185 Case w/Binder Screws	X	X	X	X	X	X	X	X
7	2	CWO-8018	104 Cable Connector Block	X	X	X	X	X	X	X	X
8	1	CWO-8052	Cable Hose Support	X	X	X	X	X	X	X	X
9	1	CWO-8053	175 Connector Plug w/O-Rings	X	X	X	X	X	X	X	X
10	1	CWO-8054	25-SA Nozzle Flux Cone	X	X	X	X	X	X	X	X
11	1	CWO-8524	50394 500 AMP Cable	X	X	X	X	X	X	X	X
*	1	CWO-8039	45-4535-15 Cable Liner	X	X						
*	1	CWO-8041	45-116-15 Cable Liner			X	X				
*	1	CWO-8042	45-332-15 Cable Liner						X		
*	1	CWO-8043	45-18-15 Cable Liner								X
*	1	CWO-8044	45H-764-15 Cable Liner							X	
*	1	CWO-8085	45-564-15 Cable Liner					X			


CW-7 DRIVE ROLL KITS

PART NUMBER	DESCRIPTION
CWO-7026-.035	DRIVE ROLL KIT .035 (0.9mm) SOLID WIRE
CWO-7026-.035C	DRIVE ROLL KIT .035 (0.9mm) CORED WIRE
CWO-7026-.052	DRIVE ROLL KIT .045-.052 (1.0-1.3mm) SOLID WIRE
CWO-7026-.052C	DRIVE ROLL KIT .045-.052 (1.0-1.3mm) CORED WIRE
CWO-7026-1/16	DRIVE ROLL KIT 1/16 (1.6mm) SOLID/CORED WIRE
CWO-7026-3/32	DRIVE ROLL KIT .068-3/32 (1.7-2.4mm) SOLID/CORED WIRE
CWO-7026-1/8	DRIVE ROLL KIT 7/64-1/8 (2.8-3.0mm) SOLID/CORED WIRE (REQUIRES MODIFICATIONS FOR 1/8" WIRE)


3-JAW EXPANDABLE CHUCKS




CWO-3660



CWO-3661



CWO-3662




CWO-3663

3-Jaw Expandable Chucks

Mounts and automatically centers the Circle Welder on nozzles with or without flanges. As shown below.

PART NUMBER	FOR NOZZLE I.D.'S	WEIGHT
CWO-3660	2"-8" (51mm-204mm)	68 lbs. (31 kg)
CWO-3661	8"-16" (204-405 mm)	36 lbs. (16 kg)
CWO-3362	10"-24" (255-610 mm)	51 lbs. (23 kg)
CWO-3663	24"-42" (610-1065 mm)	64 lbs. (29 kg)



PREVENTIVE MAINTENANCE / CW-7 CIRCLE WELDER

IMPORTANT: Make sure the input power at the power source is turned off and the 50' weld cable is disconnected from the circle welder prior to working inside the circle welder.

AFTER DAILY USE:

Refer to CW-7 Exploded View Parts List. (Pg. 10)

Racking System Item #1:

Inspect gear rack, hardened ways and wheels, remove all dirt, grease, weld spatter and rust. Check hardened ways for nicks and replace if necessary. Lubricate with a dry teflon or graphite spray lubricant. Adjust wheels for snug fit and smooth operation. Lubricate racker pinion with a dry teflon or graphite spray lubricant.

Large Horizontal Racker Item #2:

Inspect wheels and remove all dirt, grease, weld spatter and rust. Adjust wheels for snug fit and smooth operation. Lubricate racker pinion and wheels with a dry teflon or graphite spray lubricant.

Slide Bar Mounting Assembly Item #6:

Inspect hardened ways remove all dirt, grease and weld spatter. Check hardened ways for nicks and replace if necessary. Lubricate with a dry teflon or graphite spray lubricant.

Refer to CW-7 Electrical Component Chart. (Pg. 12)

Power Cable Item #4:

Inspect cable connector to make sure threads are not stripped and that the connector is not cracked. Check the cable for cuts, missing insulation and burn spots, replace if necessary.

CW-7 Collector Ring Item #11:

Inspect cable connector to make sure threads are not stripped and that the connector is not cracked. Ensure that the connector is fastened properly to the large aluminum gear item #27 on the CW-5 Exploded View Parts List.

EVERY SIX MONTHS:

Refer to CW-7 Exploded View Parts List. (Pg. 10)

Aluminum Gear Item #29

Do not grease this gear. Inspect gear teeth remove all dirt, grease and weld spatter. Lubricate with a dry teflon or graphite spray lubricant. Replace gear if excessively worn.

P.M. Motor Assembly Item #17:

Do not grease this pinion. Inspect the drive pinion. Remove all dirt, grease and weld spatter. Lubricate with a dry teflon or graphite spray lubricant. Replace pinion if excessively worn. Check set screw and tighten if necessary. Adjust motor assembly using the four adjustable mounting fasteners so that proper gear mesh is achieved between the aluminum gear item #29 and the motor drive pinion.

5" Cam Assembly Item #7:

Inspect the slide rails and the cam pinion. Remove all dirt, grease and weld spatter. Do not grease slide rails or cam pinion. Lubricate with a dry teflon or graphite spray lubricant. Replace cam pinion if excessively worn. Tighten all fasteners as needed.

Wire Reel Assembly Item #22:

Periodically coat the wire wheel shaft with a thin layer of grease as needed. Inspect the shoe assembly and replace if excessively worn.

PREVENTIVE MAINTENANCE / CW-7 CIRCLE WELDER

Refer to CW-7 Electrical Component Chart. (Pg. 12)

GMA Wire Feed Control Item #6:

Open control box, use an air hose to blow out dust and dirt. Check all wires for breaks and replace if necessary. Check all electrical connectors and plugs. If an electrical component fails refer to CWO-3332 Wire Feeder Control electrical component chart for replacement parts or return for service.

M-14 Rotation Control Item #15:

Open control box use an air hose to blow out dust and dirt. Check all wires for breaks and replace if necessary. Check all electrical connectors and plugs. If an electrical component fails refer to CWO-6110 Rotation Control electrical component chart for replacement parts or return or service.

LN-7 Wire Feeder Assembly Item #9:

Check brushes for wear. Brushes should be replaced when their length is less than 1/4 inch. Replace strain relief on wire if pulled out of motor housing.

Brush Holder & Support Item #3:

Inspect brush holder. Make sure constant tension is being applied on the brushes. Brushes should move freely within the brush holder. Check brushes for arc build-up. If brushes are pitted they will need replaced. Remove the brushes and sand them to ensure a smooth contact surface. Make sure all fasteners are tight.

Small Brush Retainer Assembly Item #8:

Inspect black brush holders for cracks and replace if needed. Check and make sure all wires are soldered properly to the holders. Replace the brushes when their length is less than 1/2 inch long. Remove the brushes and sand them to ensure a smooth contact surface. Make sure all fasteners are tight.

Terminal Block Item #13:

Inspect the plastic terminal strip and make sure it is not cracked, replace if necessary. Make sure all terminal connections are tight. Make sure all ground wires are connected to the mounting screws of the terminal strip.

EVERY TWELVE MONTHS:

Refer to CW-7 Exploded View Parts List. (Pg. 10)

1-1/2" Bearing With Fasteners Item #26:

Do not grease the bearing, it is greased for life by the manufacturer. If the grease fitting has not been removed and plugged we suggest that you do so now. Earlier models may not have been plugged at time of assembly.

P.M. Motor Assembly Item #15:

Bodine gear motor lubrication. Fill gear motor to oil level indicator with worm gear oil conforming to AGMA#5EP compounded (SAE#90) oil or Bodine lubricant (#L-23). Do not overfill.

LN-7 Wire Feeder Assembly Item #17:

Apply graphite grease to the gear teeth. Inspect the drive roll portion of the assembly, clean as necessary. Do not use solvents on the idle roll because it may wash the lubricant out of the bearings. Do not apply grease to the drive rolls.

Transmission 5:1 Assembly Item #14:

Inspect for excessive wear and tear. Keep the transmission assembly clean and lubricate with Lubriplate #630-AA.

PREVENTIVE MAINTENANCE / CW-7 CIRCLE WELDER

Refer to CW-7 Electrical Component Chart. (Pg. 12)

CW-7 Collector Item #11:

The collector ring should be sanded once a year. If the collector ring is pitted too badly it should be replaced. Inspect all wires coming out of the collector ring for cut or missing insulation. All wires should be fastened to the center shaft with a nylon cable tie. Tighten four set screws if needed.

Weld Cable Inlet 3/0 Item #12:

Ensure that the cable is fastened tightly to the collector ring. Inspect the cable for cut or missing insulation. Make sure the micarta insulation tube on the cable is in good condition. Replace the cable if necessary.

Solenoid Adaptor Kit Item #16:

Inspect for damage. Replace if necessary.

GMA Pigtail Item #5:

Inspect the cable for cuts or missing insulation. Ensure that the elbow connector is not damaged. Ensure that all terminal ends are snug. Replace cable if necessary.

WARRANTY

Limited Warranty

Model _____
Serial No. _____
Date Purchased: _____

For a period of twelve (12) months from delivery, Cypress Welding warrants to the original purchaser (does not include authorized distributors), that a new machine is free from defects in material and workmanship and agrees to repair or replace, at its option, any defective parts or machine. This warranty does not apply to machines, which after our inspection, are determined to have been damaged due to neglect, abuse, overloading, accident or improper usage. All shipping and handling charges will be paid by customer.

Cypress Welding makes no warranty of merchantability and makes no other warranty, expressed or implied, beyond the warranty expressly set forth above. Buyer's remedy for breach of warranty, hereunder, shall be limited to repair or replacement of non-conforming parts and machines. Under no circumstances shall consequential damages be recoverable.

HOW TO OBTAIN SERVICE:

If you think this machine is not operating properly, re-read the instruction manual carefully, then call your Authorized Cypress dealer/distributor. If he cannot give you the necessary service, write or phone us to tell us exactly what difficulty you have experienced. BE SURE to mention the MODEL and SERIAL numbers.